Retrotouch


# **COOKER SWITCH**

WITH A TOUCH OF GLASS<sup>TM</sup>



# FOR SOPHISTICATED KITCHENS

This stylish Crystal Cooker switch with Socket in boasts the screwless glass faceplate characteristic of our Crystal range. The elegant selection of cooker sockets match the rest of our Crystal range and brings an stunning finish to any kitchen.







+44 (0) 1293 279 426 | Sales@retrotouch.co.uk | Retrotouch.co.uk

#### **SPECIFICATIONS / FEATURES**

Our Cooker switch and socket models are designed to offer outstanding functionality while maintaining the esquisite style of our Crystal range, earning their place as the best looking cooker switch for the kitchen.





Sophisticated glass finish

Adding a touch of glass for the ultimate finish

Screwless fronts The screws are hidden giving your switch a seamless design

Easy fit terminals Providing ease of install while keeping a premium look

Fits 35mm back box Offering quick and easy installation

**10-year warranty** We've got you covered

## What's in the box

Cooker switch with Plug Socket Glass front plate in Black or White finish 2 screws for back box fixing Instruction manual

#### Specifications

1 Gang Switched UK Plug Socket
Double Pole
13 Amp Rated (Socket)
45 Amp Rated (Cooker Switch)
Glass Surround
Neon light for Cooker
Concealed Fixing Screws
150 x 90mm (Standard Double)
Fits in a 35mm Depth Back Box
Terminal size: 6mm
Operating Temperature: -5 to +40 C L
Location: Internal Use Only / IP20

#### Certifications

10-year warranty UKCA, CE & RoHS certified BS1363 & BS4177

KK € ₹

#### Models & Finishes



WHITE WITH CHROME TRIM SKU: 01840



BLACK WITH CHROME TRIM SKU: 01841



WHITE GLASS



BLACK GLASS

For videos & image gallery visit our website.





### retrotouch.co.uk/cooker

Crystal.